

Micro Urine Collection for Babies and Toddlers Not Toilet-Trained



Equipment

- 1x 70ml Yellow-top Container
- 1x Paediatric Urine Collector
- Sterile Water Wipe

Procedure

For children not toilet-trained

- The parent/carer must wash hands thoroughly.
- Cleanse child's genital area thoroughly with sterile water wipe.
- Put on the paediatric urine collector (remove backing paper from adhesive by lifting the lower left or right hand corner).
- Remove centre piece to expose the opening.
- For males, attach the bag allowing the penis to project through the opening.
- For females, attach the bag so the opening covers the upper part of the genitalia.
- As soon as possible after urine has been passed (minimum requirement is 1ml), transfer to the sterile container.
- Remove lid and hold bag over the container.
- Empty the bag by cutting the projection at the bottom corner and allowing the urine to flow into the container. Immediately replace the lid, ensuring correct threading and secure closure.
- Write patient's surname, first given name and date of birth and time/date of collection on the container.
- Refrigerate the specimen or keep in a cool place until returned to a Clinical Labs pathology collection centre.